PBS-10010B
denver.eu
03/2025

Important safety information

WARNING: Please read the safety instructions carefully before using the product for the first time and keep the instructions for future reference.

1. This product is not a toy. Keep it out of reach of children.
2. Please keep the product away from pets.
3. Warning! This power bank is with lithium polymer battery inside.
4. Do not try to open the power bank.
5. Do not expose to heat, water, moisture or direct sunlight!
6. Do not attempt to replace the battery yourself- you may damage the battery, which could cause overheating and injury. Repairs or service should only be performed by qualified personnel.
7. Battery must be recycled or disposed of separately from household waste. Do not incinerate the battery.
8. To reduce the risk of fire or electric shock, do not expose this product to rain or moisture.
9. Please remove the charging cable when the power bank is fully charged.
10. Product operating and storage temperature is from 5 degrees Celsius to 35 degrees Celsius. Under and over this temperature might affect the function.
11. Do not drop or expose to impact or shock in any way.

Item Overview

1. Type-C Input
2. Micro Input
3. USB Output
4. LED Indicator
5. Power Button

Package Contents

Power Bank
Type-C Charging Cable
User Manual

Specifications

* Battery Capacity: 10,000mAh
* Type-C/Micro Input: 5 V/2A
* USB-A Output 1/2: 5V/2A
* With Battery Level Indicator

Charging the Power Bank

1. Fully charge the power bank before using it for the first time.
2. Connect the Type-C cable to the Type-C input port of the device.
3. Connect the other end of the cable to a USB power source.
4. When all 4 LEDs are lit, the power bank is fully charged.

Please notice - All products are subject to change without any notice. We take reservations for errors and omissions in the manual.

ALL RIGHTS RESERVED, COPYRIGHT
DENVER A/S

denver.eu

Electric and electronic equipment and included batteries contains materials, components and substances that can be hazardous to your health and the environment, if the waste material (discarded electric and electronic equipment and batteries) is not handled correctly.

Electric and electronic equipment and batteries is marked with the crossed out trash can symbol, seen above. This symbol signifies that electric and electronic equipment and batteries should not be disposed of with other household waste, but should be disposed of separately.

As the end user it is important that you submit your used batteries to the appropriate and designated facility. In this manner you make sure that the batteries are recycled in accordance with legislature and will not harm the environment.

All cities have established collection points, where electric and electronic equipment and batteries can either be submitted free of charge at recycling stations and other collection sites, or be collected from the households. Addi-tional information is available at the technical department of your city

DENVER A/S
Omega 5A, Soeften
DK-8382 Hinnerup
Denmark
www.facebook.com/denver.eu

Contact

Main contact point: contact.hq@denver.eu

Nordics
Headquarter
Denver A/S
Omega 5A, Soeften
DK-8382 Hinnerup
Denmark

Phone: **+45 86 22 61 00**
(Push "1" for support)

E-Mail:
support.hq@denver.eu

For additional questions, please write to:
support.hq@denver.eu

For all other questions please write to:
contact.hq@denver.eu

Benelux
DENVER BENELUX B.V.
Barnsteinseweider 13 C-D
3903 LL Veenendaal
The Netherlands

Phone: **0900-3437623**
E-Mail: **support.nl@denver.eu**

Spain/Portugal
DENVER SPAIN S.A.
Ronda Ruipotillery Louis Lumiere, nº 23 - nave 1
Parque Tecnológico
46980 Paterna
Valencia (Spain)

Spain
Phone: **+34 960 046 883**
Mail: **support.es@denver.eu**

Portugal
Phone: **+351 1213 240 294**
E-Mail: **denver.services@outlaf.com**

Germany
Denver Germany GmbH Service
Service Center
Max-Emanuel-Str. 4
94036 Passau

Phone: **+49 851 379 369 40**

E-Mail:
support.de@denver.eu

Monday - Thursday (9:00 - 16:30
Friday (9:00 - 14:00)

Austria
Luft Premium Service GmbH
Deutschstrasse 1
1230 Wien

Phone: **+43 1 904 3080**
E-Mail: **denver@luftservice.at**

Poland
Letmetkopain Poland sp. z o.o.

ul. Czerniakowska 140
00-001 Warsaw

Phone: **61 76 35 092**
E-Mail: **denver-service@letmetkopain.pl**

Godziny pracy: 8 - 16 (poniedziałek - piątek)

If your country is not listed above, please write an email to: contact.hq@denver.eu

denver
Denver A/S
Omega 5A, Soeften
DK-8382 Hinnerup
Denmark

denver.eu
facebook.com/denver.eu

PAP