


Qoltec®



INSTRUCTIONS FOR USE AND PRECAUTIONS FOR ELECTRICAL AND ELECTRONIC PRODUCTS IN ACCORDANCE WITH THE GPSR PROCEDURE

INTRODUCTION

Thank you for purchasing a **Qoltec** product. This manual applies to electrical and electronic equipment. To ensure correct and safe use, please read the following precautions carefully before using the product.

INSTALLATION AND USE

- **Use the device only for its intended purpose** and do not modify it yourself to avoid damage and safety risks.
- Always install the device making sure beforehand that it is compatible with the system it is to work with.
- Connect the device to a suitable power source, according to the parameters specified in the product specifications.

ELECTRICAL SAFETY

- Make sure the unit is disconnected from the power source before connecting or maintaining it.
- Do not use the device if you notice damage to the cable, plug or housing.
- Avoid overloading the unit - observe the maximum load values to prevent overheating or damage.
- Never connect or disconnect the device with wet hands. This can lead to a short circuit, electric shock or damage to the device.
- Do not use the device in wet conditions unless specifically authorised by the manufacturer (e.g. waterproof or IP-certified devices).
- Do not touch damaged and uninsulated cables, this can lead to an electric shock.

PROTECTION AGAINST MECHANICAL DAMAGE

- Store the equipment in a dry place, free from dust, moisture and high temperatures.
- Avoid impacts, drops and other mechanical damage that may affect the functioning of the device.
- Use appropriate protection such as cases, covers or other protective accessories to prevent damage.

CLEANING

- Regularly remove dust and dirt from the surface of the unit using a soft, dry cloth.

- Avoid using water and aggressive chemicals, which can damage the delicate components of the appliance.
- For sensitive components (e.g. connectors, lenses), use specialised cleaning accessories.

PROTECTION AGAINST EXTREME CONDITIONS

- Do not expose the device to excessive temperatures, moisture or direct sunlight.
- Make sure the unit is away from sources of heat, liquids, chemicals or flammable materials.

CABLE MANAGEMENT

- Avoid excessive bending, twisting or strain on the cables to prevent damage.
- Store cables in an orderly manner, avoiding entanglement and exposure to water or other adverse conditions.
- Always grasp the plug when connecting or disconnecting a device.

SUPPORT OF DEVICES WITH BLUETOOTH AND WIRELESS FUNCTIONS

- Use Bluetooth devices within range according to the manufacturer's instructions, avoiding interference and connection problems.
- When using Bluetooth, set your device to pairing mode as instructed to avoid synchronisation problems.

DATA PROTECTION AND PRIVACY

- In the case of data processing devices (e.g. smart cards), ensure that adequate measures are in place to protect personal data.
- Use only authorised media and accessories to store or transfer data to avoid unauthorised access.

FAILURE AND RESPONSE

- If the unit exhibits abnormal operation, such as overheating, sparking, unusual odour or noises, immediately switch it off and disconnect it from the power supply and then contact the service centre.
- If you observe any unsafe product behaviour, contact the manufacturer urgently: Ntec Ltd.

DISPOSAL AND ENVIRONMENTAL RESPONSIBILITY

- Used appliances should be taken to an electro-waste collection point in accordance with local regulations.
- Never dispose of electronic devices in municipal waste. Make sure they are properly disposed of or recycled.

