




KB901L User's Manual

CREATE
FOR GAME

RGB Backlit Mechanical Keyboard



Keyboard Specification:

Interface Type: USB
Size: 365*138*39mm
Key Number: 88
Operating Voltage: 5V±0.25V
Operating Current: ≤200mA
Key Life: 50,000,000 times
Cable Length: 1800mm
Compatible with Windows 2000/XP/Vista/Win7/Win8/Win10

Connecting With Your Computer

1. Turn on your computer.
2. Insert the USB interface of keyboard into a USB port of your computer (better choose the USB port locating on the back of the chassis instead of those on the front).
3. Wait for 1 minute, and your keyboard will automatically read by your computer with no extra driver needed.

(Note: This is a plug & play keyboard no need of any driver.)
Status Indicator: "Caps Lock", "Win lock".

01

LED Backlit Adjustment:

FN+: 14 Lighting modes switch.

FN+: Side backlit(11 Lighting modes switch).

FN+: Indicator RGB light(11 Lighting modes switch).

FN+: Backlight color switching.

FN+: Turn on/off the backlight.

FN+: Restore keyboard factory settings(Long press for 3 seconds).

FN+: Backlit brightness increasing, there are 5 grades of backlight brightness.

FN+: Backlit brightness decreasing, there are 5 grades of backlight brightness include 1grade to turn it off.

FN+: Backlit movement speed increasing,there are 5 grades of backlight movement speeds.

FN+: Backlit movement speed decreasing,there are 5 grades of backlight movement speeds.

Backlight recording

1. First select the backlight you want to customize by FN+.

2. Press FN+ to enter the backlight recording mode, at this time the keyboard backlight is off, the indicator light is flashing, indicating that the backlight recording has begun;

3. Press the key you want to record the backlight, repeat this step to record the backlight you want;

4. When finished, press FN+ again to save and exit the backlight recording mode;

5. FN+ is fixed light effect and cannot be customized, you can switch different backlight by FN+ 

02



HAVIT

Dual System Support

FN+: Switching to Windows Mode.

FN+: Switching to MAC Mode.

MAC OS				WIN			
Shortcut Keys	Function	Shortcut Keys	Function	Shortcut Keys	Function	Shortcut Keys	Function
	F1	FN+ 	Screen brightness reduction		F1	FN+ 	My computer
	F2	FN+ 	Screen brightness plus		F2	FN+ 	Web/Home
	F3	FN+ 	Move the beginning of the file		F3	FN+ 	Email
	F4	FN+ 	Back to the desktop		F4	FN+ 	Calculator
	F5	FN+ 	Backlit brightness decreasing		F5	FN+ 	Music player
	F6	FN+ 	Backlit brightness increasing		F6	FN+ 	Stop
	F7	FN+ 	Previous		F7	FN+ 	Previous
	F8	FN+ 	Play/Pause		F8	FN+ 	Play/Pause
	F9	FN+ 	Next		F9	FN+ 	Next
	F10	FN+ 	Mute		F10	FN+ 	Mute
	F11	FN+ 	Volume -		F11	FN+ 	Volume -
	F12	FN+ 	Volume +		F12	FN+ 	Volume +

03

MAC OS				WIN			
Shortcut Keys	Function	Shortcut Keys	Function	Shortcut Keys	Function	Shortcut Keys	Function
	Calculator	FN+ 	Calculator		Calculator	FN+ 	Calculator

Keyboard lock function

Fn + : lock/unlock Win key

For more functions, please enter "<https://havitsmart.com/pages/driver-download>" to download the driver.

Note:

1. Driver support music rhythm (keyboard and computer match, in the driver set to music rhythm mode, the keyboard lights will move with the rhythm of the music in the computer).

2. The driver software model is "KB901L".

Troubleshooting steps:

1. Insert the USB cable into another USB port of the computer.

2. If you were using a USB hub, try to connect the keyboard directly with your computer.

3. It would be better to plug it into USB ports locating on the back of the chassis instead of those on the front.

4. Check USB hub for foreign objects or dust.

5. Unplug and reinsert the USB connector.

6. Restart the computer.

04