

USB-A is the type of connector which plugs into your laptop. USB-B is the end that plugs into your printer.

High quality braided shield and ferrite core connector at both ends to shield against EMF and RF interference.

*10m+ models have an in-line active booster (48 mm / 1.9" long x 25 mm / 0.98" wide) integrated half way along cable.

When used with Vision's Techconnect modular faceplate, we recommend using the TC2 USB+ active booster module with all cables longer than 5m (16.4 ft).